



Risk Assessment - Workshop - Use of a Borer / Slotter Clone of Workshop - Use of a Milling Machine.

Reference No: GLO-45475-44

Version No: 1

Assessment Approver: Kevin Jarvis

Department: Global

Date Of Assessment: 02 July 2024

Review Due Before: 07 August 2027

Lead Assessor: Geoff Goring

Team: Kevin Jarvis

Use of a borer/slotter in the machine work shop

Type	Hazard Cause	Persons Affected	Control Measures	L Overall	S Medium - Risk to be minimised and controlled so far as is reasonably practical.	T	Additional Control Measures	L Overall	S	T	Owner/Action
Health and Safety	Personal Injury Multiple causes included contact with moving parts, sharps objects, entanglement, electrical shock etc.	Volunteers & Staff	<p>1) CRITICAL - Elimination: No loose clothes, jewellery, overly long sleeves, ties or gloves to be worn. - Effective</p> <p>2) CRITICAL - Elimination: Hands will be kept clear of rotating parts such as the chuck and workpiece on the moving machine table. - Effective</p> <p>3) CRITICAL - Engineering: An 'Emergency Stop' or other stop switch should be fitted within the reach of the user. - Effective</p> <p>4) CRITICAL - Engineering: Machine guards should be fitted, clean, functional and used at all times. Consider guards for the chuck, spindle mandrel, feed shafts and lead screws if not protected by the design of the machine. - Effective</p> <p>5) CRITICAL - Engineering: Any fitted safety devices such as 'Impact Wands', safety wires, foot switches or overloads should be fitted and functional. - Effective</p> <p>6) CRITICAL - Engineering: The machine should be securely fixed to the floor or other stable and unmovable surface. Those machines that are mounted on wheels should be securely fixed whilst in use to stop them from moving. - Effective</p> <p>7) CRITICAL - Engineering: The machine must be switched off and power isolated and locked out where possible before any maintenance activity takes place. - Effective</p> <p>8) CRITICAL - Engineering: Cutting fluids will be used as appropriate and maintained to remain in a suitable condition for use. - Effective</p> <p>9) CRITICAL - Engineering: The work piece shall be mounted to the machine and properly secured. - Effective</p> <p>10) CRITICAL - Engineering: The cutting tool must be carefully checked for security before starting the machine. - Effective</p> <p>11) CRITICAL - Engineering: Chuck keys and any other tools are to be removed before starting the machine. - Effective</p> <p>12) CRITICAL - Engineering: The machine must be stopped before the work piece is removed from the machine. - Effective</p> <p>13) CRITICAL - Engineering: The machine must always be stopped before taking any measurements. - Effective</p> <p>14) CRITICAL - Engineering: Coolant nozzles must not be adjusted when the machine is in operation. - Effective</p> <p>15) CRITICAL - Administrative: Only competent and authorised staff should use the equipment. - Effective</p> <p>16) CRITICAL - Administrative: The equipment should be mechanically and electrically maintained regularly and accurate records of maintenance activity should be kept. All safety features should be tested. - Effective</p> <p>17) CRITICAL - Administrative: A hair net or cap shall be worn for staff with long hair. - Effective</p> <p>18) CRITICAL - Administrative: The machine must never be left unsupervised if energised. - Effective</p> <p>19) CRITICAL - Administrative: Swarf must not be allowed to accumulate or become entangled with the work piece. The machine is to be cleaned before and after working. - Effective</p> <p>20) CRITICAL - Administrative: The standing area for the operator must be clean, free from debris and not slippery. - Effective</p>	2 x 4 = 8	Medium - Risk to be minimised and controlled so far as is reasonably practical.		<p>1) Engineering: Consider the use of interlocked guards - Improvable</p> <p>2) Engineering: Lifting aids are to be used for positioning heavy work pieces in the machine or for changing heavy chucks or faceplates.. - Improvable</p> <p>3) Engineering: If the workpiece extends beyond the end of the table it must be guarded or protected by barriers and supported as appropriate. - Improvable</p> <p>4) Engineering: Where machine guards are not fitted extra care should be taken to avoid entanglement with moving parts or ejection of materials. - Improvable</p> <p>5) Administrative: Make sure that there is plenty of space around the machine so that persons passing do not bump into the machine operator. - Improvable</p> <p>6) PPE: Be aware of the potential for swarf to be sharp and consider using gloves and a suitable implement when cleaning swarf from the machine - Effective</p>	2 x 4 = 8	Medium - Risk to be minimised and controlled so far as is reasonably practical.		Geoff Goring - Arrange for the assessment, fitting and use of appropriate guards where these are not present due to the age and/or design of the machine. Raise bespoke RA's. Part of planning and improvement is to re-arrange the shop floor

CONTINUES ON NEXT PAGE



Gloucestershire Warwickshire Steam Railway Plc
Risk Assessment for Workshop - Use of a Borer / Slotter - Global

Type	Hazard Cause	Persons Affected	Control Measures	L Overall	S	T	Additional Control Measures	L Overall	S	T	Owner/Action
			21) CRITICAL - Administrative: Be aware of potential of swarf to be ejected from the machine. - Effective 22) CRITICAL - Administrative: Only the user and any trainees are to be near to the machine when it is in operation. - Effective 23) CRITICAL - Administrative: Loose tooling and other equipment or rags etc. must not be kept on the machine or allowed to obstruct the work area. - Effective 24) CRITICAL - PPE: Eye protection, overalls or dust coat and steel toe-capped footwear to be worn. - Effective								

Score and Control Measure Notes.

Risk is medium due to potential injury.
All control measures must be followed.
The risk remains medium.

COSHH Assessments

The following COSHH assessments are applicable to this risk assessment:

- COSHH-44517-36 - Astro - Sol A
Ends



Appendix



Reference: UI-45490-919
Borer - Example Boring machine